


**TURNTABLE QUICK START GUIDE**

AT-LPW40WN / AT-LPW30TK




**INFORMATION**


取扱説明書  
User Manual  
Manuel de l'utilisateur  
Bedienungsanleitung  
Manuale dell'utente  
Manual de usuario  
Manual do Usuário  
Руководство пользователя  
用户手册  
使用説明書  
사용설명서




**CONTENTS**



**PREPARATION**




**CONNECTION**




**STOP**


1



2



3




4




**CLEANING**

For details about turntable and cartridge care accessories, visit [www.audio-technica.com](http://www.audio-technica.com).

**Stylus**




**Record**




**PLAY**


1




2



3



4



5

